



SIEMENS EDA

Valor™ ODB++ Design Viewer User Guide

Release vNPI 2211
November 2022

Unpublished work. © 2022 Siemens

This Documentation contains trade secrets or otherwise confidential information owned by Siemens Industry Software Inc. or its affiliates (collectively, "Siemens"), or its licensors. Access to and use of this Documentation is strictly limited as set forth in Customer's applicable agreement(s) with Siemens. This Documentation may not be copied, distributed, or otherwise disclosed by Customer without the express written permission of Siemens, and may not be used in any way not expressly authorized by Siemens.

This Documentation is for information and instruction purposes. Siemens reserves the right to make changes in specifications and other information contained in this Documentation without prior notice, and the reader should, in all cases, consult Siemens to determine whether any changes have been made.

No representation or other affirmation of fact contained in this Documentation shall be deemed to be a warranty or give rise to any liability of Siemens whatsoever.

If you have a signed license agreement with Siemens for the product with which this Documentation will be used, your use of this Documentation is subject to the scope of license and the software protection and security provisions of that agreement. If you do not have such a signed license agreement, your use is subject to the Siemens Universal Customer Agreement, which may be viewed at <https://www.sw.siemens.com/en-US/sw-terms/base/uca/>, as supplemented by the product specific terms which may be viewed at <https://www.sw.siemens.com/en-US/sw-terms/supplements/>.

SIEMENS MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS DOCUMENTATION INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF INTELLECTUAL PROPERTY. SIEMENS SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, LOST DATA OR PROFITS, EVEN IF SUCH DAMAGES WERE FORESEEABLE, ARISING OUT OF OR RELATED TO THIS DOCUMENTATION OR THE INFORMATION CONTAINED IN IT, EVEN IF SIEMENS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TRADEMARKS: The trademarks, logos, and service marks (collectively, "Marks") used herein are the property of Siemens or other parties. No one is permitted to use these Marks without the prior written consent of Siemens or the owner of the Marks, as applicable. The use herein of third party Marks is not an attempt to indicate Siemens as a source of a product, but is intended to indicate a product from, or associated with, a particular third party. A list of Siemens' Marks may be viewed at: www.plm.automation.siemens.com/global/en/legal/trademarks.html. The registered trademark Linux[®] is used pursuant to a sublicense from LMI, the exclusive licensee of Linus Torvalds, owner of the mark on a world-wide basis.

About Siemens Digital Industries Software

Siemens Digital Industries Software is a leading global provider of product life cycle management (PLM) software and services with 7 million licensed seats and 71,000 customers worldwide. Headquartered in Plano, Texas, Siemens Digital Industries Software works collaboratively with companies to deliver open solutions that help them turn more ideas into successful products. For more information on Siemens Digital Industries Software products and services, visit www.siemens.com/plm.

Support Center: support.sw.siemens.com

Send Feedback on Documentation: support.sw.siemens.com/doc_feedback_form

Table of Contents

Chapter 1	
ODB++Design Viewer	5
ODB++Design Viewer Window	6
Viewing the Step and Repeat Table	14

Chapter 1

ODB++Design Viewer


You can use the Valor ODB++Design Viewer to examine the step of a product model that is stored in an ODB++ directory structure. You can open a step in an ODB++ directory structure that has been compressed into any of these file types: *tgz*, *gz*, *Z*, *tar*, or *zip*. You can view the graphic of the step and information about each layer of the step.

ODB++Design Viewer Window	6
Viewing the Step and Repeat Table	14

ODB++Design Viewer Window

You use the ODB++Design Viewer to view the graphic of the product model step, and information about the layers of the step.

Figure 1-1. ODB++Design Viewer Window



Objects

Table 1-1. ODB++Design Viewer Window - Panes








Pane	Description
ODB++ Layer List 	Used to choose layers to be displayed in the board viewer. The color of the cell in the layer column () indicates the color in which the layer is displayed. You can use the feature histogram or the component histogram of a layer to highlight groups of entities in the graphic area. See “Using the Features Histogram to Select or Highlight Features” and “Using the Components Histogram to Select or Highlight Components” in <i>Getting Started With ODB++Design</i> .
Board Viewer pane 	Displays the graphic representation of the chosen layers. The X and Y coordinates of the current mouse pointer position are displayed below the graphic.
Component Filter 	To display this pane, choose View > Component Filter or click the Component Filter tool () See Using the Component Filter Pane to Find Components ” in <i>Getting Started With ODB++Design</i> .
Overview pane 	Use the Zoom area tool () to drag a rectangle in this pane, or in the board viewer, to zoom to that area in the board viewer.

Table 1-1. ODB++Design Viewer Window - Panes (cont.)

Pane	Description
Data bar <pre>Highlighted: 119; BOT #41 TP106 Part: ??? Pkg: TP30 BOT 1 Pins X=3.162 Y=-2.377 L=0.075 W=0.075 H=0 Rot=0.0 T= P=0</pre>	<p>The data bar at the bottom of the window displays information about highlighted features or components.</p> <p>When multiple features or components are highlighted by double-click, the number of highlighted features or components is prefixed to the details of the first feature or component.</p>

Table 1-2. ODB++Design Viewer Window - File Menu Options

Tool	File Menu Option	Description
-	Open Job	Opens the Product Model List dialog box so you can open a product model whose steps you want to view.
-	Open Step	Lists the steps of the current product model, so you can open the step you want to view. This option is unavailable if the product model has only one step.
-	Exit	Exit the ODB++Design Viewer.

Table 1-3. ODB++Design Viewer Window - Actions Menu Options




Tool	Actions Menu Option	Description
-	View Orientation	Open the “ View Orientation ” dialog box that enables you to rotate, mirror, or flip the board view.
 	Highlight Highlight-2	<p>Click the tool and click a feature to be highlighted in the colors set for Highlighted and Highlighted-2.</p> <p>A symbol in the Color of features for each layer column of the ODB++ Layer List indicates whether one or two features are highlighted on the layer.</p> 

Table 1-3. ODB++Design Viewer Window - Actions Menu Options (cont.)







Tool	Actions Menu Option	Description
	Highlight NET	<p>Open the Highlight CAD Nets dialog box in which you can use two tabs to highlight CAD nets in two different colors.</p> <p>Choose a tab and select a CAD net to be highlighted, or press Shift or Ctrl to select multiple nets.</p> <p>The legend lists the names of the selected nets separated by semi-colons (;). The color in which the selected nets are displayed is indicated.</p> <div data-bbox="803 688 1390 1333" data-label="Image"> </div> <p>To view the features of the highlighted net on the currently displayed layers only, select the option “Show on viewed layers only”.</p>
	Clear Highlighted	Clear highlighting applied using Highlight or Highlight-2.
   	Measure Between Points Measure Between Features Measure Between Nets Measure Annular Rings	<p>Opens a sub-menu where you can choose whether to measure between points, features, nets, or annular rings.</p> <p>See “Measuring Distances” in <i>Getting Started With ODB++Design</i>.</p>

Table 1-3. ODB++Design Viewer Window - Actions Menu Options (cont.)


Tool	Actions Menu Option	Description
	Snap	Open the Snap dialog box in which you can define snap and grid options.

Table 1-4. ODB++Design Viewer Window - View Menu Options










Tool	View Menu Option	Description
-	Step & Repeat Table	See “ Viewing the Step and Repeat Table ” on page 14.
	Matrix	Opens the “ Matrix ” window displaying the layer construction, layer types and subtypes, polarity, drill intersection with board layers (for drilled via holes), and sub-panel nesting.
	Zoom In, Zoom Out	Zoom in or zoom out.
	Zoom Area	Invoke the zoom area tool for drawing a zoom rectangle in the board viewer or overview pane.
	Zoom PopView	Display a magnified view of a section of the board. You can open more than one popview window at the same time. See “ Zooming and Panning ” in <i>Getting Started With ODB++Design</i> .
	Zoom Home	Zoom to a view that fits the board in the graphic area.
	Previous Zoom	Returns to the zoom factor that was in effect before the most recent zoom action.
	Pan XY	Open the Pan XY dialog box.  Type the X and Y coordinates to be brought to the center of the graphic area and click Goto .
	Pan Left, Pan Right, Pan Up, Pan Down	Pan left, right, up, or down. (shortcuts: keyboard arrow keys).

Table 1-4. ODB++Design Viewer Window - View Menu Options (cont.)




Tool	View Menu Option	Description
	View Properties	Open the “ Component Information ” or “ Feature Information ” dialog box to view detailed information about the selected item.
	Component Filter	Open the component filter pane. See “ Using the Component Filter Pane to Find Components ” in <i>Getting Started With ODB++Design</i> .
	Color Settings	Open the “ Colors ” dialog box that enables you to set colors for displaying items in the graphic area.
-	Component Options	Open the “ Component Display Options ” dialog box that enables you to configure some aspects of how components are displayed in component layers.
-	Show Populated Components Only / Show All Components	Toggle between showing all components and showing only populated components.
-	Control	Open the “ Control ” dialog box that enables you to control the display of data in the graphic area.

Table 1-5. ODB++Design Viewer Window - Help Menu Options

Tool	View Menu Option	Description
-	View Help	Opens documentation for the ODB++Design Viewer. (shortcut: F1)
-	About	Displays ODB++Design Viewer version and system information.

Table 1-6. ODB++Design Viewer Window - Board Viewer Right-Click Menu Options


Option	Description
Zoom area	Invokes the zoom area tool so you can drag a zoom rectangle in the board viewer pane or overview pane. Equivalent to clicking the Zoom Area () tool.
Popview	Display a magnified view of a section of the board. You can open more than one popview window at the same time. See “ Zooming and Panning ” in <i>Getting Started With ODB++Design</i> .

Table 1-6. ODB++Design Viewer Window - Board Viewer Right-Click Menu Options (cont.)





Option	Description
Measure	<p>Invokes the measure tool so you can measure the distance between two points.</p> <p>Equivalent to clicking the Measure () tool.</p> <p>See “Measuring Distances” in <i>Getting Started With ODB++Design</i>.</p>
Highlight	<p>Invokes the highlight tool so you can highlight a feature or component.</p> <p>Equivalent to clicking the Highlight a feature or a component () tool.</p>
Clear highlighted	<p>Clears all highlighted features and components.</p> <p>Equivalent to clicking the Clear Highlighted () tool.</p>
Toggle pile-up selection	<p>Overlapping features make it difficult to choose an individual feature from among them. Pile-up selection mode provides a list of overlapping features that are at the board location at which you clicked, from which you can choose the feature you want.</p> 

Table 1-7. ODB++Design Viewer Window - Board Viewer Shortcuts


Shortcut	Description
Ctrl+a	Invokes the Zoom area tool for one actuation. After you have dragged a rectangle in the board viewer pane or in the overview pane, the tool that was previously in effect is in effect.
Ctrl+d down arrow	Pan down with 90% overlap.
Ctrl+e	Click on the board graphic and press Ctrl+e to pan the board viewer pane to center that point in the pane.
Ctrl+h Ctrl+Home	Zooms to a view that fits the entire board in the graphic area.
Ctrl+i Page Up	Zooms in. Equivalent to clicking the Zoom In tool ().

Table 1-7. ODB++Design Viewer Window - Board Viewer Shortcuts (cont.)







Shortcut	Description
Ctrl+l left arrow	Pan left with 90% overlap.
Ctrl+m	Toggles between a four layer display and more than four layers.
Ctrl+o Page Down	Zooms out. Equivalent to clicking the Zoom Out tool ().
Ctrl+r right arrow	Pan right with 90% overlap.
Ctrl+Shift+d Shift+down arrow	Pan down with 10% overlap.
Ctrl+Shift+l Shift+left arrow	Pan left with 10% overlap.
Ctrl+Shift+r Shift+right arrow	Pan right with 10% overlap.
Ctrl+Shift+Space	Returns to the zoomed display in memory after zooming other areas.
Ctrl+Shift+u Shift+up arrow	Pan up with 10% overlap.
Ctrl+Space	Copies the current zoomed display to memory.
Ctrl+u up arrow	Pan up with 90% overlap.
Ctrl+w	Toggles the view of features among these modes:  full,  outline, or  width off

Table 1-7. ODB++Design Viewer Window - Board Viewer Shortcuts (cont.)

Shortcut	Description
middle-click	<p>The middle button can be used for these pan and zoom functions:</p> <ul style="list-style-type: none"> • Center in Graphic Area — Middle-click a point in the graphic area. The click point is panned to the center of the graphic area. • Zoom Out — With the middle button, drag a diagonal up and to the right, ending at the point you want in the center of the graphic area. • Zoom In — With the middle button, drag a diagonal down and to the left, ending at the point you want in the center of the graphic area. • Zoom to Area — With the middle button, drag a diagonal down and to the right, so that the start and end of the line you drag define a rectangular area to which you want to zoom. • Zoom Home — With the middle button, drag a diagonal up and to the left. The view zooms so that the whole board is displayed centered in the graphic area.
Shift+Home	<p>Zooms to a view that fits the highlighted component in the board area. Equivalent to clicking the Zoom Home tool (.</p>

Usage Notes


- Click one or more layers in the ODB++ Layer List to display them in the board viewer.
- To use the board viewer shortcuts, you must place the mouse pointer in the board viewer pane.
- Click the **Toggle Units** tool () on the toolbar to toggle the measurement units displayed in the X and Y coordinates under the board viewer, and for the Measure tool, between inches and mm.

Viewing the Step and Repeat Table

If your product model contains step and repeat data, you can view panelization information in the Step & Repeat Table dialog box.

Procedure

1. Choose **View > Step & Repeat Table**.



2. View the panelization information in the table:

Column	Description
Step	Name of the step.
Anchor Point	Anchor point of the step.
Nx, Ny	Number of steps in the X and Y directions.
Dx, Dy	Distance between steps in the X and Y directions, in the indicated units of measure.
Angle	Rotation angle for the step inside the panel.
Flip	Indication of whether the step is flipped about the Y-axis.

